



# Trek 4300 Bicycle Kickstand Replacement

This guide demonstrates how to replace the kickstand.

Written By: Emily OConnor



## INTRODUCTION

The kickstand has three parts: a bracket, a bolt, and the stand. To replace the kickstand the bracket and bolt will need to be removed to allow for the removal of the stand.



### TOOLS:

- [1/4" Hex adapter](#) (1)
- [T shaped handle socket screwdriver](#) (1)



### PARTS:

- [Trek Kickstand](#) (1)

## Step 1 — Loosen Bracket



- Flip the bike over so it is balanced and resting on the handlebar and the bike seat.
  - Using a socket screwdriver with a hex adapter, loosen the bolt that is holding the kickstand and bracket in place.
- i** This may require a moderate amount of strength. Make sure you have the proper hex adapter as to not strip the bolt.



## Step 2 — Remove the kickstand



- Once the bolt is loose, unscrew it the rest of the way by hand.
  - Remove the bolt. There should now be three separate pieces: the bolt, the bracket, and the kickstand.
- i** Make sure to note the position of the bracket before you remove the bolt completely

To replace the new kickstand, follow these instructions in reverse order.

This document was last generated on 2017-06-27 06:50:41 PM.